360-degree Rotating Shaker Instruction Manual

FK-360 has obtained CE Marking and Taiwan patent No. M575318

CE

Instructions for use

- 1. Loosen the screw with a 10mm wrench. After placing the shakers on the holders, adjust the top presses until they touch the top of the shakers firmly.
- 2. Adjust the desired seconds with the timer. When the time is up, the timer will stop automatically. (Do not adjust the timer while the machine is running)
- 3. Turn on the power. (Please ensure that the machine voltage is 110V/220V).
- 4. Press the START switch.
- 5. To temporarily turn off the power, press the OFF switch. Do not adjust the timer directly.
- 6. Please lubricate the slide frequently [with mechanical/food grade lubricant].
- Do not flush the electronic parts with water or allow them to get wet to avoid malfunction.

Precautions

- When cleaning the machine, do not clean the electronic parts and bearings.
 Clean the product by wiping it with a dry cloth.
- 2. Do not adjust the timer directly while the machine is running to avoid timer malfunction.
- 3. Place the machine on a stable and non-wobbly table to avoid affecting the quality of the machine.



Machine dimensions	36 x 30 x 30cm
Voltage	110V / 60Hz
Watt/ampere	60W / 1.3A
Motor rotational speed	1500rpm CONT: 30 min.
Thank you for using the shaker. I wish you a thriving business.	